

## LEVER ON ROSE

### - OVAL MULTI POINT SPRUNG CARTRIDGE

## FITTING INSTRUCTIONS

1. Supplied spindle  
*Ensure the spindle is inserted with the groove (1A) facing the grub screw (7)*
2. Oval multi point cartridge  
*Note the back portion of the cartridge (2A) is to be recessed into the door*
3. Back to back bolts
4. Outer rose cover
5. Nylon washer
6. Lever handle
7. Grub screw

**Note:** We strongly recommend requesting a sample before committing to any cutting or drilling

