



1. Unsprung cartridge (T&R specific)
Indicator side has spindle pre fixed (1A)
2. Back to back bolts & wood screws
The back to back bolts (2A) are to be located to the left and right of the spindle. The wood screws (2B) are to be located above and below the spindle
3. Outer rose cover
4. Nylon washer
5. Turn
6. Grub screw

Note: We strongly recommend requesting a sample before committing to any cutting or drilling